
Meridian 1

ISDN Primary Rate Interface

Installation

Document Number: 553-2901-200
Document Release: Standard 11.00
Date: August 1996

© 1989, 1996
All rights reserved

Printed in the United States of America

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules, and the radio interference regulations of Industry Canada. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at this own expense.

SL-1 and Meridian 1 are trademarks of Northern Telecom.

Revision history

August 1996

Issue 11.00 released as Standard for Generic X11 Release 22.

December 1995

Issue 10.00 released as Standard for Generic X11 Release 21B.

July 1995

Issue 9.00 released as Standard for Generic X11 Release 21A.

December 1994

Standard, Release 8.00.

October 31, 1993

Standard, Release 7.00.

August 1, 1993

Standard, Release 6.00.

April 1, 1993

Standard, Release 5.00.

December 31, 1992

Standard, Release 4.00.

December 1, 1991

Standard, Release 3.00.

December 20, 1990

Standard, Release 2.00.

December 20, 1989

Standard, Release 1.00.

Contents

Introduction	1
Document organization	1
References	3
Note to installers	4
 Primary Rate Interface equipment: overview	 5
ISDN Signaling Link hardware	9
QPC720 PRI	10
Power requirements	10
QPC720 faceplate	11
Cable requirements	11
Carrier interface	13
Echo Canceller interface	13
64 T-link version 2 protocol	14
QPC757 DCHI/NT6D80 MSDL	15
Power requirements	15
Interface to PRI	15
QPC757/NT6D80 faceplate	15
NT6D80 MSDL	18
Power requirements	18
MSDL/PRI interface	18
MSDL faceplate	18
Clock operation	20
Tracking mode	20
Free run (non-tracking) mode	20
Holdover mode	20

Reference clock errors	20
Automatic clock recovery	22
Automatic clock switching	22
DTI to PRI conversion	23
PRI installation: ST, STE, 21, 21E	27
PRI circuit card locations	27
Cable requirements	27
Installing the QPC720 PRI	28
Removing the QPC720 PRI	34
PRI installation: RT	35
PRI circuit card locations	35
Cable requirements	35
Installing the QPC720 PRI	36
Removing the QPC720 PRI	42
PRI installation: NT, 51/51C, 61/61C	43
PRI circuit card locations	43
Cable requirements	43
Installing the QPC720 PRI	44
Removing the QPC720 PRI	46
PRI installation: XT, 71	55
PRI circuit card locations	55
Cable requirements	55
Installing the QPC720 PRI	55
Removing the QPC720 PRI	64
PRI installation: 81/ 81C	65
PRI circuit card locations	65
Cable requirements	65
Installing the QPC720 PRI	65
Removing the QPC720 PRI	73

Clock Controller Installation	75
Determining slots and shelves	76
Replacing a Clock Controller	79
Installing a Clock Controller	79
Starting the Clock Controller	79
Clock Controller commands	79
Installing the Clock Controller in a single group	82
DCHI installation for all systems	87
Installing the QPC757 DCHI	87
D-channel parameter downloading	91
Removing the QPC757 DCHI	92
MSDL installation for all systems	93
Installing the MSDL	93
NTD12 Dual-port DTI/PRI card description and installation	99
NT5D12 Dual-port DTI/PRI (DDP) card overview	99
Supported software releases	100
NTBK51AA daughterboard	101
D-Channel and MSDL interface	102
DDP faceplate	104
System capacity and performance	110
Physical capacity	110
D-Channel capacity	110
CPU capacity	110
Power requirements	111
Testability and diagnostics	112
Hardware required for DDP configuration	113
Cabling requirements	115
Trunk Tip/Ring cables	116
Reference clock cables	121
MSDL/DCHI cables	122

Cabling diagrams	124
Clocking	127
Clock operation	127
Reference clock errors	129
Automatic clock recovery	129
Automatic clock switching	130
Clocking configurations	130
DDP installation and removal	137
DDP circuit card locations	137
Port definitions	137
Replacement of a digital trunk (QPC720/QPC472) by a DDP card	138
DDP switch settings	139
General Purpose Switches	139
Trunk interface switches	140
Ring ground switches	141
DCH mode and address select switches	142
Installing the NT5D12 DDP	146
Removing the NT5D12 DDP	148
Configuring the NT5D12 DDP	149
DDCH installation for all systems	150
Installing the DDCH daughterboard	151
DDCH removal for all systems	152
Removing the DDCH daughterboard	152
Echo Celler for all systems	153
PRI to Echo Celler pin assignments	153
Electromagnetic Interference	154
ISL installation for all systems	157
ISL configurations	157
DCHI switch settings	157
MSDL switch settings	159
Shared mode	160
Dedicated mode using leased line	161
Dedicated mode using dial-up modem	161

Dedicated mode using PRI/DTI trunks	164
ISL installation	166
ISL dedicated mode (digital and analog)	167
ISL shared mode	167
PRI cabling information	169
QCAD128/NT8D83xx	169
QCAD129/NT9J93xx	171
QCAD133/NT8D83xx	172
QCAD328	173
NT8D74 Clock Controller to InterGroup cable	174
NT8D75 Clock Controller to Clock Controller cable	174
NT8D79 PRI/DTI to Clock Controller cable	174
NT8D83 PRI/DTI to I/O cable	175
NT8D85 Network to PE cable	175
NT8D86 Network to I/O cable	176
NT8D97AX PRI/DTI I/O to MDF cable	176
NT9J93AD PRI/DTI Echo Canceller to I/O cable	176
NTND26 PRI to MSDL cables	176
NTND27 MSDL to I/O panel cables	177
NTND98 PRI to I/O panel cables	177
ISDN card slot positions	179

List of figures

Figure 1	
PRI hardware	7
Figure 2	
QPC720 PRI faceplate layout	12
Figure 3	
QPC757 DCHI faceplate layout	17
Figure 4	
NT6D80 MSDL faceplate layout	19
Figure 5	
Clock controller primary and secondary tracking	21
Figure 6	
PRI circuit card (QPC720) option settings	24
Figure 7	
ST, STE, 21, 21E cabling without Echo Canceller	31
Figure 8	
ST, STE, 21, 21E cabling with Echo Canceller	32
Figure 9	
PRI card (QPC720) switch settings	33
Figure 10	
RT cabling without Echo Canceller	39
Figure 11	
RT cabling with Echo Canceller	40
Figure 12	
PRI card (QPC720) switch settings	41

Figure 13	
Half group cabling without Echo Celler	49
Figure 14	
Half group cabling with Echo Celler	50
Figure 15	
Single group cabling without Echo Celler (NT, 61/61C)	51
Figure 16	
Single group cabling with Echo Celler (NT, 61/61C)	52
Figure 17	
PRI card (QPC720) switch settings	53
Figure 18	
XT, 71 cabling without Echo Celler	58
Figure 19	
XT, 71 cabling with Echo Celler	59
Figure 20	
Option switch settings for PRI circuit card	60
Figure 21	
Option 81/81C cabling without Echo Celler	67
Figure 22	
81/81C cabling with Echo Celler	68
Figure 23	
Option switch settings for PRI circuit card	69
Figure 24	
QPC757 option and PRI/ISL high speed programming switch settings	89
Figure 25	
QPC757 option switch settings for PRI/ISL low speed programming	90
Figure 26	
MSDL card layout	95
Figure 27 - NT5D12 faceplate - general view	105
Figure 28 - DDP faceplate - detailed view	106
Figure 29 - DDP cabling for Meridian 1 and Meridian SL-1 systems with an I/O panel	125

Figure 30 - DDP cabling for Meridian SL-1 systems without an I/O panel	
126	
Figure 31 - Clock Controller primary and secondary tracking	128
Figure 32 - Clock Controller - Option 1	133
Figure 33 - Clock Controller - Option 2	134
Figure 34 - Clock Controller - Option 3	135
Figure 35 - Clock Controller - Option 4	136
Figure 36 - Switches Functional Areas	144
Figure 37 - Switch Default Settings	145
Figure 38	
PRI to Echo Canceller cabling	155
Figure 39	
ISL settings	158
Figure 40	
MSDL/ISL settings	159
Figure 41	
ISL in shared mode	160
Figure 42	
ISL dedicated mode: using leased line	161
Figure 43	
ISL dedicated mode: using dial-up Hayes Smartmodem 2400	162
Figure 44	
ISL dedicated mode: using PRI/DTI trunk	165

List of tables

Table 1	
Minimum ROM requirements by machine type and X11 release	8
Table 2	
QPC720 PRI: external connectors	11
Table 3	
QPC720 PRI: cables and cable lengths	14
Table 4	
Transmission equalization switch settings for QPC720 PRI/DTI mode	25
Table 5	
Shelf and slot location of QPC720 in ST and option 21	28
Table 6	
Transmission equalization switch settings for PRI	29
Table 7	
Cable connections and destinations for ST, STE, 21, 21E	30
Table 8	
Shelf and slot location of QPC720 in RT	36
Table 9	
Transmission equalization switch settings for PRI	37
Table 10	
Cable connections and destinations for RT	38
Table 11	
Shelf and slot location of QPC720 in NT or option 61	44
Table 12	
Transmission equalization switch settings for PRI	47

Table 13	
Cable connections and destinations for NT, 51/51C, 61/61C	48
Table 14	
Shelf and slot location of QPC720 in XN, XT, and option 71	56
Table 15	
Transmission equalization switch settings for PRI	61
Table 16	
Cable connections and destinations for XT, 71	62
Table 17	
Shelf and slot location of QPC720 in 81	66
Table 18	
Transmission equalization switch settings for PRI	70
Table 19	
Cable connections and destinations for 81/81C	71
Table 20	
Clock Controller shelves and slots	76
Table 21	
Clock Controller switch settings for QPC471 vintage A	76
Table 22	
Clock Controller switch settings for QPC471 vintages B through G .	77
Table 23	
Clock Controller switch settings for QPC471 vintage H	78
Table 24	
Clock Controller switch settings for QPC775	78
Table 25	
MSDL switch settings	96
Table 26 - Supported software releases on the NT5D12	100
Table 27 - DCHI/MSDL Receiver Ready control signals	103
Table 28 - External connectors and LEDs	107
Table 29 - DDP power requirements	111
Table 30- NT5D16AA cable pins	117

Table 31- NT5D17AA cable pins	119
Table 32 - Clock Controller options- summary	131
Table 33 - Clock Controller options - description	132
Table 34- General purpose switch settings	139
Table 35- Trunk interface transmission mode switch settings	140
Table 36- Trunk interface line build out switch settings	140
Table 37 - Trunk interface receiver impedance switch settings	141
Table 38- Ring ground switch settings	141
Table 39 - DCH mode and address select switch settings	142
Table 40- NTBK51AA daughterboard address select switch settings .	143
Table 41	
PRI to Echo Canceller pin assignments	153
Table 42	
Echo Canceller operating parameters	154
Table 43	
Echo Canceller initialization procedures	154
Table 44	
Pin assignment for D-channel RS-232 interface	163
Table 45	
QCAD128/NT8D83xx wire list	170
Table 46	
QCAD129/NT9J93xx wire list	171
Table 47	
QCAD133/NT8D83xx wire list	172
Table 48	
QCAD328 wire list	173
Table 49	
Card slot positions for 21/ 21E, 51/51C, 61/61C, 71, and 81/81C	179
Table 50	
Card slot positions for ST, STE, RT, NT, XT	180
